


Testing Logistics (Setup to Teardown)



Mike Evans – Laboratory Lead Test Engineer

INL Tech-to-Market (T2M) Workshop

May 19-20, 2015

www.inl.gov



More exercise for some means the batteries are dead in the remote again.



Independently evaluate batteries for the transportation sector.


- Performance assessment of energy storage devices against established targets
- Nationally recognized as high quality, high fidelity, and independent test center
- Assorted chemistries and formats
- Cycling, calendar life and cold crank with elevated temperatures
- Cells (5-12V) up to 250 amps, modules (40-60V) 275 amps, and packs (500-1000V) 500 amps

***Battery Test Center named DOE Core Capability for
Electrochemical Performance Testing***

Objective

Independent, science-based performance assessment of energy storage devices.

- Environmental control
- Software analysis tools for data analysis and reporting.
- Standards developed for data acquisition, analysis, quality and management.
- **Protocols & Procedures**
 - Internationally accepted manuals for performance assessment of energy storage systems.
 - **Lead National Laboratory** for technical content and authorship with support from DOE and USABC.
- **Quality Results**
 - Flexible state-of-the-art energy storage test facility capable of supporting current and future development activities.
 - Rigorous NIST traceable calibration procedures for in depth uncertainty analysis.
 - Temperature controlled testing for reliable and repeatable results.



Equipment

- INL Battery Test Center
 - 20,000ft² lab space
 - 705 cell test channels
 - 27 module test channels
 - 7 pack test channels
 - >100 controllable thermal chambers
 - Vibration test system



Industry Partnerships

Lithium Ion



Lead Acid



Ultracapacitor



Equipment

- **Armature (640 mm or 25.2 in diameter)**

- Sine force peak: 13,000 lbf
- Random force peak: 12,500 lbf
- Half sine peak shock force: 26,660 lbf
- Velocity sine peak: 1.8 m/s (70.9 in/s)
- Acceleration peak:
 - Sine: 392 m/s²
 - Random: 392 m/s² (40g_n)
- Displacement (continuous) peak to peak:
 - 63.5 mm (2.5 in)




- **Horizontal and Vertical Axis Testing**

- Magnesium slip plate (x & y axis): 96" x 72" with hydrostatic guide bearings on a 4" grid
- Head expander (z-axis):
 - 72" x 72" with specimen mounting inserts on a 4" grid
 - Fully removable for smaller test articles
- Weights:
 - Head expander: 1349 lbs
 - Slip plate: 875 lbs




- **8 Channel Data Acquisition Controller**

Workflow



Receiving



Receiving




Receiving



Receiving



Receiving



02.09.2015 14:13



05.13.2015 11:24


Receiving

Jig Assembly Directions


Materials: metal fixture, 2 glass fiber plates, 2 rubber pads





Step 1: Place each rubber pad on a glass fiber plate and put the cell in between the two rubber pads as shown below. Place the pads 1 cm away from the top of the cell (where the cell name is located), and directly in line with the edge of side that the tabs are closest to.



Step 2: Place the cell in the metal fixture and position it so that the black rod would rest on the middle of the glass fiber plate. Lower the rod to the glass fiber plate.



Step 3: Set a gauge to 5 inch-pounds of torque and use it to push down the rod further.



Step 4: Ready for testing.


Receiving



02.24.2015 17:15



05.13.2015 11:22



02.12.2015 16:02

Please use the test plan for suggested cycling parameters.





02.27.2015




Cells




Cells



Cells



Packs






Setup




Fixtures




Standard fixture



Standard fixture



CAM Controller



Summary

- The INL Battery Test Center is the lead DOE laboratory for advanced automotive battery performance testing.
 - 20,000 square feet of lab space with >700 test channels for advanced energy storage testing.
- INL is continuing to support DOE and USABC with science-based performance testing and assessment of candidate battery technologies for various vehicle platform applications.
 - Rigorous NIST traceable calibration procedures for in depth uncertainty analysis.
- INL has strong capabilities in advanced battery diagnostics and prognostics for improved state-of-health assessment.
 - On-going research activities in collaboration with DOE, NHTSA, SNL, and University of Maryland.
- *The INL Battery Test Center (BTC) evaluated 535 cells, 23 modules, and 3 packs for a total of 561 articles in FY-2014*



iNL

Idaho National Laboratory